

## HERE'S HOW IT WORKS...


### LAUNDRY WRAP JUNIOR

Comes in a self dispensing shipping carton along with a separate slide cutter for safe, speedy cut-off - simply follow the instructions for set-up and you're in business.

When film is gone - **TOSS THE BOX**, save slide cutter for next box.

### LAUNDRY WRAP JUNIOR

Comes in 30" and 36" widths.



When ordering use:  
 PC 37583000 for 30" Slide Cutter  
 PC 37583600 for 36" Slide Cutter  
 PC 39293000 for 30" Film  
 PC 39293600 for 36" Film  
 PC 3761000 Retaining Device

1. Open carton and remove the Protective Bridge.
2. Take out and secure rubber non-skid feet, or secure Retaining Device to table or wall.
3. Cut or push out perforated dispenser slot and finger slots.
4. Insert slide cutter into opening.
5. Pull film out of dispensing slot—Lay over slide cutter.



1. Pull Film up & out from dispenser box; lay over edge and let hang - do not crumple!



6. Push air out of package and fold second side over - smooth with hand.



2. Place laundry upside down on film.



7. Flip package over - press down - film will seal to itself - No heat required.



3. Bring draped film up and over.



4. Cut film, and bring film over laundry toward you - overlapping #3.



5. Pull ends out to avoid bunching; fold one end of film up and over.

## AEP/BORDEN

125 PHILLIPS AVE.  
 SOUTH HACKENSACK, NJ 07606  
 TEL. (201) 641-6600 • (800) 782-3456  
 FAX (201) 807-2567

